

LinMot[®]



**MC-Link with
Ethernet/IP Interface
User Manual**

This document applies to the following controllers:
B8050-ML-IP

© 2016 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying,

recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note:

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation.

NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 4.5 / Whp, January 2019

Table of Content

1 SYSTEM OVERVIEW	4
1.1 REFERENCES	4
2 CONNECTING TO THE ETHERNET/IP NETWORK	5
2.1 PIN ASSIGNMENT OF THE CONNECTORS X17-X18	5
2.2 DEFAULT IP ADDRESS SETTINGS	5
3 SETUP IN THE PLC	6
3.1 RSLINX CLASSIC	6
3.2 LINMOT CONFIGURATION IN THE PLC	7
4 ETHERNET/IP PARAMETERS	12
4.1 PARAMETERS	12
5 REALTIME IO DATA MAPPING	14
5.1 O ->T AND T->O MAPPING WITH CONFIGURATION MODULE	14
5.1.1 <i>O → T Mapping of one axis</i>	14
5.1.2 <i>T → O Mapping of one axis</i>	14
5.2 PLC SETUP WITH DIFFERENT NUMBERS OF AXIS	15
5.2.1 <i>PLC Setup with 1 Axis</i>	15
5.2.2 <i>PLC Setup with 2 Axis</i>	16
5.2.3 <i>PLC Setup with 3 Axis</i>	17
5.2.4 <i>PLC Setup with 4 Axis</i>	18
5.2.5 <i>PLC Setup with 5 Axis</i>	19
5.2.6 <i>PLC Setup with 6 Axis</i>	20
5.2.7 <i>PLC Setup with 7 Axis</i>	21
5.2.8 <i>PLC Setup with 8 Axis</i>	22
6 SPECIAL AXIS ERRORS FOR (M)B8050-ML-IP SYSTEMS	23
7 CONTACT ADDRESSES	24

1 System overview

The LinMot Ethernet/IP controllers have the following functionalities:

Device Property	Value / Remark
Minimal Ethernet/IP cycle time	2 ms
DHCP -Support	Supported
EDS Support	Not yet supported from AB
IEEE1588 (CIP-Synch)	For 3 rd parties not supported from AB
DLR Support (Device Level Ring Protocol)	No

Ethernet/IP is a real time Ethernet protocol based on the standard Ethernet protocols TCP/IP and UDP/IP.

For further information on Ethernet/IP please visit: <http://www.odva.org>

1.1 References


All User Manuals are distributed with the LinMot-Talk configuration software the newest version could be downloaded from the LinMot homepage in the download section.

Ref	Title	Source
1	User Manual Motion Control SW	www.linmot.com
2	LinMot Drive Configuration over Fieldbus Interfaces SG4	www.linmot.com
3	Usermanual_MC_Link_with_Ethernet_IP_SG5.pdf	www.linmot.com

2 Connecting to the Ethernet/IP Network



2.1 Pin Assignment of the Connectors X17-X18

The Ethernet/IP connector is a standard RJ45 female connector with a pin assignment as defined by EIA/TIA T568B:

X17 – X18		RealTime Ethernet Connector	
	Pin	Wire color code	Assignment 100BASE-TX
	1	WHT/ORG	Rx+
	2	ORG	Rx-
	3	WHT/GRN	Tx+
	4	BLU	-
	5	WHT/BLU	-
	6	GRN	Tx-
	7	WHT/BRN	-
	8	BRN	-
case	-	-	
RJ-45	Use standard patch cables (twisted pair, S/UTP, AWG26) for wiring. This type of cable is usually referred to as a "Cat5e-Cable".		

2.2 Default IP Address Settings

The default IP address is 192.168.001.xxx where the last byte xxx is defined via the two Hex-Switches S1 and S2, where S1 sets the high digit and S2 the low digit.

S1, S2:	IP Selectors	
	S1	Bus ID High (0h...Fh)
	S2	Bus ID Low (0h...Fh)



IMPORTANT: The switch position S1 = S2 = 0 (factory default setting) defines acquiring IP address via DHCP.

3 Setup in the PLC




IMPORTANT: Use only AB PLC firmware 18.0 or higher!


The following steps describe the integration of a LinMot Ethernet/IP controller in the PLC. In the example an Allen Bradley master PLC is used. RSLinx tool can only be used to see if the device is on the network and under which IP-address it can be accessed. The whole configuration is done in the PLC, which is described in Chapter 3.2.

3.1 RSLinx Classic

In the RSLinx the LinMot device should occur under the defined IP address as “Unrecognized Device” B8050-ML-IP




LinMot device with the IP address 192.168.1.89 in the RSLinx tool



LinMot device properties

3.2 LinMot Configuration in the PLC

The LinMot can be configured in the I/O configuration section, in the Ethernet section as a New Module



Then you have to select in the Communications Module the ETHERNET-MODULE

The screenshot shows the RSLogix 5000 software interface. The main window title is "RSLogix 5000 - Test_10 in Test_ML_18_2ms.ACD [1756-L61 18.11]". The path is "AB_ETHIP-2\192.168.1.251\Backplane\1".

The Controller Organizer on the left shows a tree structure for "Controller Test_10". Under "I/O Configuration", there is a "1756 Backplane, 1756-A4" folder containing "Ethernet" sub-folders. One "Ethernet" folder contains "ETHERNET-MODULE X_Axis1_8" and "1756-EN2TR ENIP_1". Another "Ethernet" folder contains "[1] 1756-L61 Test_10" and "[2] 1756-ENBT ENIP2".

The "Select Module" dialog box is open, displaying a table of modules:

Module	Description	Vendor
1788-EN2DN/A	1788 Ethernet to DeviceNet Linking Device	Allen-Bradley
1788-ENBT/A	1788 10/100 Mbps Ethernet Bridge, Twisted-Pair Media	Allen-Bradley
1788-EWEB/A	1788 10/100 Mbps Ethernet Bridge w/Enhanced Web Serv..	Allen-Bradley
1794-AENT	1794 10/100 Mbps Ethernet Adapter, Twisted-Pair Media	Allen-Bradley
DriveLogix5730 Etherne..	10/100 Mbps Ethernet Port on DriveLogix5730	Allen-Bradley
ETHERNET-BRIDGE	Generic EtherNet/IP CIP Bridge	Allen-Bradley
ETHERNET-MODULE	Generic Ethernet Module	Allen-Bradley
EtherNet/IP	SoftLogix5800 EtherNet/IP	Allen-Bradley
PSSCENA	Ethernet Adapter, Twisted-Pair Media	Parker Hannifin Corp.
Stratix 8000	26 Port Managed Switch	Allen-Bradley
Stratix 8000	22 Port Managed Switch	Allen-Bradley
Stratix 8000	18 Port Managed Switch	Allen-Bradley
Stratix 8000	14 Port Managed Switch	Allen-Bradley
Stratix 8000	10 Port Managed Switch	Allen-Bradley
Stratix 8000	6 Port Managed Switch	Allen-Bradley

Buttons at the bottom of the dialog include "Find...", "Add Favorite", "By Category", "By Vendor", "Favorites", "OK", "Cancel", and "Help".


Under the Module Properties you can define the module specific data:

- Name
- Comm Format in the example a 16 bit Format is chosen!
- IP Address
- Input Assembly instance and size
- Output Assembly Instance and size


Be careful defining these parameters, because only a correct setting will run in the in the Ethernet/IP network. Only the name can be defined freely.

The screenshot shows the 'Module Properties: ENIP_1 (ETHERNET-MODULE 1.1)' dialog box. The 'General' tab is selected, and the 'Connection' sub-tab is active. The 'Name' field contains 'X_Axis1_8'. The 'Comm Format' is set to 'Data - INT'. The 'Address / Host Name' section has 'IP Address' selected with the value '192 . 168 . 1 . 89'. The 'Connection Parameters' section shows 'Input' with an assembly instance of 18 and a size of 104 (16-bit), 'Output' with an assembly instance of 28 and a size of 128 (16-bit), and 'Configuration' with a value of 1 and a size of 0 (8-bit). The 'Status Input' and 'Status Output' fields are empty. The status at the bottom left is 'Offline'. Buttons for 'OK', 'Cancel', 'Apply', and 'Help' are at the bottom right.

In the Connection Tab of the Module Properties the desired cycle time is specified in the range between 2ms and 3200ms.





Then the configuration/program can be downloaded and you can change to the online view.



It is recommended to use Unicast Connection type, with this type no problems were known.

If all was set up correctly the LinMot module status should be running





In The LinMot-Talk configuration software the Ethernet/IP connection state can be watched under variables\Ethernet/IP:O ->T, T-> O config. If everything was set up correctly, the connection state should change to established when powered on after a certain time. In this state both counters O → T and T → O should count up depending on the configured period time.

4 Ethernet/IP Parameters

4.1 Parameters

The Ethernet/IP interface has an additional parameter tree branch (Parameters → Ethernet/IP Intf), which can be configured with the distributed LinMot-Talk software.

With these parameters, the Ethernet/IP communication parameters can be configured.

The LinMot-Talk software can be downloaded from <http://www.linmot.com> under the section download, software & manuals.

Ethernet/IP Intf\ Dis-/Enable

With the Dis-/Enable parameter the LinMot controller can be run without the Ethernet Ethernet/IP interface going online. So in a first step the system can be configured and run without any bus connection.

Ethernet/IP\ Dis-/Enable	
Disable	The controller runs without Ethernet/IP.
Enable	The controller runs with Ethernet/IP connection.



IMPORTANT: If the Ethernet/IP interface is disabled, the integrated Ethernet/IP switch is not powered! No messages will be sent to other devices connected to the Ethernet-Network via the LinMot controller.

Ethernet/IP Intf\Ethernet Configuration\ IP Configuration Mode

This parameter defines how the IP address is assigned.

<i>Ethernet/IP Intf\Ethernet Configuration\ IP configuration Mode</i>	
DHCP	IP address is acquired via DHCP mechanism.
Static by IP Configuration	IP address is defined with parameters only.
Static with Hex Switches S1 and S2 (DHCP)	IP address is defined with parameters and the last byte is defined with the value of the HEX switches S1 and S2. The default IP address setting is 192.168.001.xxx (xxx stands for the value of the Hex switches S1 and S2)



IMPORTANT: The Switch value **S1 = 0** and **S2 = 0** (factory default setting) acquiring IP address via **DHCP** is activated instead.

Ethernet/IP Int\Ethernet Configuration\IP Configuration

In this section the parameters for the IP address netmask, default gateway and multicast IP address are located.

Ethernet/IP Int\Ethernet Configuration\IP Configuration	
IP address 1st Byte	Highest byte of IP address
IP address 2nd Byte	Mid high byte of IP address
IP address 3rd Byte	Mid low byte of IP address
IP address 4th Byte	Lowest byte of IP address
Netmask 1st Byte	Highest byte of Netmask
Netmask 2nd Byte	Mid high byte of Netmask
Netmask 3rd Byte	Mid low byte of Netmask
Netmask 4th Byte	Lowest byte of Netmask
Default Gateway 1st Byte	Highest byte of Default Gateway
Default Gateway 2nd Byte	Mid high byte of Default Gateway
Default Gateway 3rd Byte	Mid low byte of Default Gateway
Default Gateway 4th Byte	Lowest byte of Default Gateway

5 Realtime IO Data Mapping

For each axis a container of data is exchanged which allows to control the axis and even to configure it over the exchanged real time data.

5.1 O ->T and T->O Mapping With Configuration Module

With this real time IO configuration, an additional configuration module is mapped into the IO data communication. The functionality of this module is same for the different fieldbus interfaces. For this reason, the functionality is described in documentation [2] "Drive Configuration over Fieldbus".

5.1.1 O → T Mapping of one axis

In this real time IO Mapping the 16 bit control word the 16 bit motion command header and motion command parameters are exchanged. The size of this mapping is 32 bytes or **16 words** for each configured axis.

O-> T Data Mapping of one axis		
<i>Byte Offset</i>	<i>Description</i>	<i>Size / Type</i>
00h	MC SW_ControlWord	Uint16 / Bit coded
02h	MC SW_MotionCommandHeader	Uint16 / 12Bit Command 4Bit count nibble
04h	MC SW_MotionCommandPar Bytes 00..03	Uint32 / Command specific
08h	MC SW_MotionCommandPar Bytes 04..07	Uint32 / Command specific
0Ch	MC SW_MotionCommandPar Bytes 08..11	Uint32 / Command specific
10h	MC SW_MotionCommandPar Bytes 12..15	Uint32 / Command specific
14h	MC SW_MotionCommandPar Bytes 16..19	Uint32 / Command specific
18h	Cfg Module Control Word	Uint16
1Ah	Cfg Module Index/..	Uint16
2Ch	Cfg Module Value/..	Uint32/Sint32

5.1.2 T → O Mapping of one axis



In this real time IO mapping the StateVar for the main state machine and several other helpful data are exchanged. The size of this mapping is 26 bytes or **13 words** for each configured axis.

Assembly Class Instance 24		
<i>Byte Offset</i>	<i>Description</i>	<i>Size / Type</i>
00h	MC SW_StateVar	Uint16 / coded state depending
02h	MC SW_StatusWord	Uint16 / Bit coded
04h	MC SW_WarnWord	Uint16 / Bit coded
06h	MC SW_DemandPosition	Int32 / Position [100nm]
0Ah	MC SW_ActualPosition	Int32 / Position [100nm]
0Eh	MC SW_DemandCurrent	Int32 / Current [1mA]
12h	Cfg Module Status Word	Uint16
14h	Cfg Module Index/..	Uint16
16h	Cfg Module Value/..	Uint32/Sint32



The use of the Control word and Motion Command interface is described in [1]. The real time configuration module is described in [2].

5.2 PLC Setup with different numbers of Axis



5.2.1 PLC Setup with 1 Axis





5.2.2 PLC Setup with 2 Axis





5.2.3 PLC Setup with 3 Axis





5.2.4 PLC Setup with 4 Axis





5.2.5 PLC Setup with 5 Axis





5.2.6 PLC Setup with 6 Axis



5.2.7 PLC Setup with 7 Axis



5.2.8 PLC Setup with 8 Axis



6 Special Axis Errors for (M)B8050-ML-IP Systems

In some special cases the MC-Link controller modifies the status word and error codes in the process data to the PLC:

Error Codes	Description
0xA0	Axis not present
0xA1	Connection to axis has been lost

These errors are not logged in the ErrorLog of the (M)B8050, since they are not errors generated by that device. The (M)B8050 merely modifies the data sent to the PLC to indicate these errors there.

No Connection

A connection has never been established with the device, e.g. because no device is present or because of faulty cabling.

Process Data from the MC-Link Device to the PLC	Value	Description
Axis_x StateVar	0x04A0	Error 0xA0 is indicated
Axis_x StatusWord	0x0088	Error and warning flags are set
Axis_x Warn Word	0x4080	Not Homed and Intf warning flags are set
Axis_x Demand Current	0x0000	Demand current is indicated as 0

Connection Lost

A connection has once been established, but the device doesn't communicate anymore.

Process Data from the MC-Link Device to the PLC	Value	Description
Axis_x StateVar	0x04A1	Error 0xA1 is indicated
Axis_x StatusWord	0xFFFF 0x0008	Last valid value is preserved and error flag is forced
Axis_x Warn Word	0xFFFF 0x4000	Last valid value is preserved and Intf Warn flag is forced
Axis_x Demand Current	0xFFFF	Last valid value is preserved

7 Contact Addresses

SWITZERLAND

NTI AG / LinMot
Bodenaeckerstrasse 2
CH-8957 Spreitenbach

Sales and Administration: +41 56 419 91 91
office@linmot.com

Tech. Support: +41 56 544 71 00
support@linmot.com
<http://www.linmot.com/support>

Tech. Support (Skype): support.linmot

Fax: +41 56 419 91 92
Web: <http://www.linmot.com>

USA

LinMot, Inc.
N1922 State Road 120, Unit 1
Lake Geneva, WI 53147
USA

Phone: 262-743-2555

E-Mail: us-sales@linmot.com
Web: <http://www.linmot-usa.com>

Please visit <http://www.linmot.com/contact> to find the distributor closest to you.

Smart solutions are...

