

Installation Guide Power Supply

ENG

Type S02-72/1000

Power range 1000 W







1	Gen	eral Information	. 3
	1.1	Introduction	. 3
	1.2	Explanation of Symbols	. 3
	1.3	Qualified Personnel	. 3
	1.4	Liability	. 3
	1.5	Copyright	. 3
2	Safe	ty Instructions	. 4
	2.1	Personal Safety	. 4
	2.2	Application as directed	. 4
	2.3	Transport, Storage	. 4
	2.4	Installation	. 4
	2.5	Electrical Connection	. 5
	2.6	Operation	. 5
	2.7	Protection of Persons	. 5
3	Mair	ns Connection and Grounding	. 6
4	Desc	cription of the Connectors / Interfaces	. 7
	4.1	PE	. 7
	4.2	X30	. 7
	4.3	X56	. 7
5	LED	Blink Codes	. 7
6	Phys	sical Dimension	. 8
7	Outp	out Voltage Regulation	. 9
8	Pow	er Boost	. 9
9	Para	Illel Connection	. 9
1(0	rdering Information	10
11	l In	ternational Certificates	10
12	2 D	eclaration of Conformity and CE-marking	16
13	3 U	K Declaration of Conformity UKCA-Marking	17



1 General Information

1.1 Introduction

Observe the following safety instructions and the instructions on the unit (the term "unit" in the following refers to a single power supply module) as well as all the information in this manual in order to prevent danger to persons and hazards or damage to the unit and other connected products.

1.2 Explanation of Symbols



Triangular warning symbols warn against a danger.



Round command symbols tell what to do.

1.3 Qualified Personnel

All work such as transport, installation, commissioning and service is only allowed to be carried out by qualified personnel. Qualified personnel in the sense of the safety instructions in this documentation are persons who are familiar with the transport, installation, assembly, commissioning and operation of the product and who have the appropriate qualifications.

This manual must be read carefully before transport, installation, commissioning, service and all safety-related information must be adhered to.

1.4 Liability

NTI AG (as manufacturer of LinMot linear motors and MagSpring products) excludes all liability for damages and expenses caused by incorrect use of the products. This also applies to false applications, which are caused by NTI AG's own data and notes, for example in the course of sales, support or application activities. It is the sole responsibility of the user to check the information and information provided by NTI AG regarding their safety-relevant correctness. In addition, the entire responsibility for safety-related product functionality lies exclusively with the user. Product warranties are void if products are used with stators, sliders, servo drives or cables not manufactured by NTI AG unless such use was specifically approved by NTI AG. NTI AG's warranty is limited to repair or replacement as stated in our standard warranty policy as described in our "terms and conditions" previously supplied to the purchaser of our equipment (please request copy of same if not otherwise available). Further reference is made to our general terms and conditions.

1.5 Copyright

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for training purposes, or translating, in whole or in part, without the prior written consent of NTI AG. LinMot® is a registered trademark of NTI AG.

2 Safety Instructions

2.1 Personal Safety



For your personal safety

Disregarding the following safety measures can lead to severe injury to persons and damage to material:

- Only use the product as directed.
- Never commission the product in the event of visible damage.
- Never commission the product before assembly has been completed.
- Do not carry out any technical changes on the product.
- Only use the accessories approved for the product.
- Only use original spare parts from LinMot.
- Observe all regulations for the prevention of accidents, directives and laws applicable on site.
- Transport, installation, commissioning and maintenance work must only be carried out by qualified personnel.
 - Observe IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC report 664 or DIN VDE 0110 and all national regulations for the prevention of accidents.
 - According to the basic safety information, qualified, skilled personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.
- Observe all specifications in this documentation.
 - This is the condition for safe and trouble–free operation and the achievement of the specified product features.
 - The procedural notes and circuit details described in this documentation are only proposals. It is up to the user to check whether they can be transferred to the particular applications. NTI AG / LinMot does not accept any liability for the suitability of the procedures and circuit proposals described.
- LinMot servo drives, power supplies and the accessory components can include live and moving parts (depending on their type of protection) during operation. Surfaces can be hot.
 - Non-authorized removal of the required cover, inappropriate use, incorrect installation or operation create the risk of severe injury to persons or damage to material assets.
 - For more information, please see the documentation.
- High amounts of energy are produced in the power supply. Therefore, it is required to wear personal
 protective equipment (body protection, headgear, eye protection, hand guard).

2.2 Application as directed

- LinMot power supplies are components, which are designed for installation in electrical systems or machines. They are not to be used as domestic appliances, but only for industrial purposes according to EN 61000-3-2.
- When power supplies are installed into machines, commissioning (i.e. starting of the operation as directed) is prohibited until it is proven that the machine complies with the regulations of the EC Directive 2006/42/EG (Machinery Directive); EN 60204 must be observed.
- Commissioning (i.e. starting of the operation as directed) is only allowed when there is compliance with the EMC Directive (2014/30/EU).
- The technical data and supply conditions can be obtained from the nameplate and the documentation. They must be strictly observed.

2.3 Transport, Storage

- Please observe the notes on transport, storage, and appropriate handling.
- Observe the climatic conditions according to the technical data.

2.4 Installation

- The power supply must be installed and cooled according to the instructions given in the corresponding documentation.
- The ambient air must not exceed degree of pollution 2 according to EN IEC 61800-5-1.



- Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport or handling. Do not touch any electronic components and contacts.
- Power supplies contain electrostatic sensitive devices, which can easily be damaged by inappropriate handling. Do not damage or destroy any electrical components since this might endanger your health!

2.5 Electrical Connection



When working on live power supplies, observe the applicable national regulations for the prevention of accidents.



The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross–sections, circuit breakers, fuses, PE connection). Additional information can be obtained from the documentation.



This product can cause high-frequency interferences in non-industrial environments, which can require measures for interference suppression.

2.6 Operation

- If necessary, systems containing switching power supplies must be equipped with additional monitoring and protective devices in accordance with the applicable safety regulations (e.g. law on technical equipment, regulations for the prevention of accidents).
- After the power supply has been disconnected from the supply voltage, all live components and power
 connections must not be touched immediately because capacitors can still be charged. Please observe
 the corresponding stickers on the power supply. All protection covers and doors must be shut during
 operation.

2.7 Protection of Persons



The power terminals L1, L2, L3 and PWR+, PGND remain energized for a maximum of five minutes after the power supply has been disconnected.



Before servicing, disconnect supply, wait 5 minutes and measure between PWR+ and PGND to be sure that the capacitors have discharged below 42 VDC.



The housing of the power supply can have an operating temperature of > 80 °C: Contact with the heat sink results in burns.

3 Mains Connection and Grounding




Figure 1: Mains connection, grounding and overvoltage category (OVC)



In order to assure a safe and error free operation, and to avoid severe damage to system components, <u>all system components must be well grounded to protective earth PE.</u> This includes both LinMot and all other control system components on the same ground bus.



Each system component should be tied directly to the ground bus **(star pattern)**. Daisy chaining from component to component is forbidden.



Power supply connectors must not be connected or disconnected while DC voltage is present. (Capacitors in the power supply may not fully discharge for several minutes after input voltage has been disconnected). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or drives.



Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code / Canadian Electrical Code, and any additional local codes.




<u>Do not switch Power Supply DC Voltage.</u> All power supply switching and E-Stop breaks should be done to the AC supply voltage of the power supply. Failure to observe these precautions may result in severe damage to the power supply unit.




4 Description of the Connectors / Interfaces


4.1 PE



4.2 X30



4.3 X56




5 LED Blink Codes





6 Physical Dimension




in mm

Figure 2: Drawing of the power supply

S02-72/1000-xS Power Supplies		
Width	mm	67
Height	mm	240
Height with fixings	mm	272
Depth	mm	193
Weight	kg	2.6
Mounting screws Mounting distance	mm	up to M5 257 - 262
Case, degree of protection	IP	20
Storage temperature	°C	-2540
Transport temperature	°C	-2570
Operating temperature	°C	040 at rated data
Relative humidity		< 95% (non-condensing)
Pollution		Pollution degree 2 acc. EN IEC 61800-5-1
Altitude		< 2000 m above sea level
Max. power dissipation	W	100
Mounting place		Control cabinet with minimum protection class IP54
Mounting position		vertical
Minimum distance between surrounding components and air admission and air exit holes	mm	50

7 Output Voltage Regulation



8 Power Boost

The power supply has a power boost functionality which provides up to 300% of the nominal load for up to 2 seconds.

After a power boost longer than 0.5 seconds, or if the total boost time in the last 4 seconds was longer than 0.5 seconds, the current is limited to the nominal current until a cooldown period has passed. The cooldown period can be calculated with Figure 3. Below 0.5 seconds, no boost break is necessary. The RMS power of the power supply should not exceed 1 kW with the power boost included.




Figure 3: Boost time versus required break time

9 Parallel Connection

Up to three power supplies can be connected in parallel. The power supply detects automatically the parallel connection. The connected wires have to be adjusted to the maximal current. The connectors of the power supply are rated for 41 A. The Power Boost is not synchronized but still available.




10 Ordering Information

Item	Description	Item-No.
S02-72/1000	Power Supply 72 V/1000 W, 3x400-480 VAC	0150-4535

11 International Certificates

Europe	See chapter 12 "Declaration of Conformity and CE-marking"
UK CA	See chapter 13 UK Declaration of Conformity UKCA-Marking
IECEE CB SCHEME	Ref. Certif. No. CH-11541
CUL US	All products marked with this symbol are tested and listed by Underwriters Laboratories and the production facilities are checked quarterly by an UL inspector. This mark is valid for the USA and Canada and eases certification of your machines and systems in these areas. File number E316095 UL 61800-5-1 Power Conversion Equipment CSA C22.2 Industrial Control Equipment





TO1 V04



Certificate Number

UL-US-2205770-0 E316095-20220222

Report Reference Date

24-Feb-2022

Issued to:

NTI AG Bodenaeckerstr 2 SPREITENBACH 8957

Switzerland

This is to certify that

NMMS - Power Conversion Equipment

representative samples of

See Addendum Page for Product Designation(s).

Have been investigated by UL in accordance with the

Standard(s) indicated on this Certificate.

Standard(s) for Safety:

UL 61800-5-1, 1st Ed., Issue Date: 2012-06-08, Revision

Date: 2021-02-11

Additional Information:

See the UL Online Certifications Directory at

https://iq.ulprospector.com for additional information

This Certificate of Compliance does not provide authorization to apply the UL Mark. Only the UL Follow-Up Services Procedure provides authorization to apply the UL Mark.

Only those products bearing the UL Mark should be considered as being UL Certified and covered under UL's Follow-Up Services.

Look for the UL Certification Mark on the product.



Bruce Mahrenholz, Director North American Certification Program

UL LLC

Any information and documentation involving UL Mark services are provided on behalf of UL LLC (UL) or any authorized licensee of UL. For questions, please contact a local UL Customer Service Representative at https://ul.com/aboutul/locations/





 Certificate Number
 UL-US-2205770-0

 Report Reference
 E316095-20220222

Date 24-Feb-2022

This is to certify that representative samples of the product as specified on this certificate were tested according to the current UL requirements

Model	Category Description
S02-72/1000	Open Type, Power Conversion Equipment, Non-Isolated Power Supply



Bruce Mahrenholz, Director North American Certification Program

UL LLC

Any information and documentation involving UL Mark services are provided on behalf of UL LLC (UL) or any authorized licensee of UL. For questions, please contact a local UL Customer Service Representative at https://bul.com/aboutul/locations/





Certificate Number UL-CA-2205785-0 Report Reference E316095-20220222

> Date 24-Feb-2022

NTI AG Issued to:

Bodenaeckerstr 2 SPREITENBACH 8957

Switzerland

NMMS7 - Power Conversion Equipment Certified for This is to certify that

representative samples of Canada

See Addendum Page for Product Designation(s).

Have been investigated by UL in accordance with the

Standard(s) indicated on this Certificate.

CSA C22.2 NO. 274, 2nd Ed., Issue Date: 2017-04-01, Standard(s) for Safety:

Revision Date: 2017-04-01

Additional Information: See the UL Online Certifications Directory at

https://iq.ulprospector.com for additional information

This Certificate of Compliance does not provide authorization to apply the UL Mark. Only the UL Follow-Up Services Procedure provides authorization to apply the UL Mark.

Only those products bearing the UL Mark should be considered as being UL Certified and covered under UL's Follow-Up Services.

Look for the UL Certification Mark on the product.



tion and documentation involving UL Mark services are provided on behalf of UL LLC (UL) or any aut cal UL Customer Service Representative at http://discom/abouts/discontinue/





Certificate Number UL-CA-2205785-0 Report Reference E316095-20220222

Date 24-Feb-2022

This is to certify that representative samples of the product as specified on this certificate were tested according to the current UL requirements

Model	Category Description
S02-72/1000	Open Type, Power Conversion Equipment, Non-Isolated Power Supply



Any information and documentation involving UL Mark services are provided on behalf of UL LLC (UL) or any authorized licensee of UL. For quest contact a local UL Customer Service Representative at https://lul.com/aboutul/locations/





12 Declaration of Conformity and CE-marking

NTI AG / LinMot ® Bodenaeckerstrasse 2 8957 Spreitenbach Switzerland

Tel.: +41 (0)56 419 91 91 Fax: +41 (0)56 419 91 92

declares under sole responsibility the compliance of the products:

Power supplies of the Series S02-72/1000

with the

Low Voltag Directive 2014/35/EU

Applied harmonized standard:

EN 61800-5-1: 2007

EMC Directive 2014/30/EU

Applied harmonized standards:

EN 61000-6-2: 2005 (Immunity for industrial environments)

EN 61000-6-4: 2007 + A1:2011 (Emission for industrial environments)

EN 61000-6-4: 2019

According to the EMC directive, the listed devices are not independently operable products.

Compliance of the directive requires the correct installation of the product, the observance of specific installation guides and product documentation. This was tested on specific system configurations.

The safety instructions of the manuals are to be considered.

The product must be mounted and used in strict accordance with the installation instructions contained within the installation guide, a copy of which may be obtained from NTI AG.

Company: NTI AG

Spreitenbach, 29.12.2021

pullen

Dr.-Ing. Ronald Rohner

CEO NTI AG

Dr.-Ing. Marco Hitz

RESPONSIBLE FOR DOCUMENTATION



13 UK Declaration of Conformity UKCA-Marking

NTI AG / LinMot ® Bodenaeckerstrasse 2 8957 Spreitenbach Switzerland

Tel.: +41 (0)56 419 91 91 Fax: +41 (0)56 419 91 92

declares under sole responsibility the compliance of the products:

Power supplies of the Series S02-72/1000

with the

Electrical Equipment (Safety) Regulations 2016 SI 2016 No. 1101

Applied designated standards:

EN 61800-5-1: 2007

EMC Regulation S.I. 2016 No. 1091.

Applied designated standards:

EN 61000-6-2: 2005 (Immunity for industrial environments)

EN 61000-6-4: 2007 + A1:2011 (Emission for industrial environments)

EN 61000-6-4: 2019

According to the EMC regulation, the listed devices are not independently operable products.

Compliance of the regulation requires the correct installation of the product, the observance of specific installation guides and product documentation. This was tested on specific system configurations.

The safety instructions of the manuals are to be considered.

The product must be mounted and used in strict accordance with the installation instructions contained within the installation guide, a copy of which may be obtained from NTI AG.

Company: NTI AGSpreitenbach, 29.12.2021

Dr.-Ing. Ronald Rohner

fullum

CEO NTI AG

Dr.-Ing. Marco Hitz

RESPONSIBLE FOR DOCUMENTATION

ALL LINEAR MOTION FROM A SINGLE SOURCE

Europe / Asia Headquarters

NTI AG - LinMot & MagSpring

Bodenaeckerstrasse 2 CH-8957 Spreitenbach

Switzerland

Sales / Administration: +41 56 419 91 91

office@linmot.com

Tech. Support: +41 56 544 71 00

support@linmot.com

North / South America Headquarters

LinMot USA Inc.

N1922 State Road 120, Unit 1 Lake Geneva, WI 53147

USA

Sales / Administration: 262.743.2555

usasales@linmot.com

Tech. Support: 262.743.2555

usasupport@linmot.com

Web: https://www.linmot.com/ Web: https://www.linmot-usa.com/

Visit https://linmot.com/contact/ to find a distributor near you.

© 2024 NTI AG / LinMot Subject to alterations